



# VLTOR

WEAPON SYSTEMS

## Installation Instructions for VLTOR's KeyMod™ Light Mounts

VLTOR Weapon Systems  
3735 N. Romero Road  
Tucson, Arizona 85705

Phone: 520-408-1944  
Fax: 520-293-8807  
Email: [support@vltor.com](mailto:support@vltor.com)



Improper installation can result in damage. Do not attempt installation if you are not familiar with the firearm, tools and techniques involved. You are responsible for any damage or injury resulting from the improper use or installation of this product.

These instructions apply to the following VLTOR Light Mounts, including the following:

- KM-SMI KeyMod™ Light Mount
- KM-MLM KeyMod™ Millennium Light Mount
- KM-SLM KeyMod™ Scout Light Mount

**\*\*\*\*\* ALWAYS ENSURE THAT THE FIREARM IS UNLOADED PRIOR TO \*\*\*\*\*  
\*\*\*\*\* INSTALLATION\*\*\*\*\***

1. Install the light into the rings for the KM-SMI or use the manufacturer provided hardware to install either the Millennium or Scout light onto the appropriate VLTOR KeyMod™ mount.
2. With the screws loosened but not removed, place the mount onto the handguard section desired. Drop the screws into the large end of the KeyMod™ slot. The foot of the KeyMod™ screw will be facing the small end of the KeyMod™ slot.
3. Slide the mount forward until it stops. Press down on the mount to ensure it is flush to the handguard and tighten down the screws.

### Installation Tips

- When installing multiple KeyMod™ accessories, start with the forward most accessory.